

Motion Sensor LED Cabinet Light

User Manual

Model: CP-CL04



***PLEASE NOTE: Once the remote has been used, even in auto mode, the remote overrides the switch function selected on the light itself. To reset, switch the unit to OFF and then back to ON or AUTO mode* This will need to be repeated after each remote use if you are wanting to be able to use the AUTO (Motion Sensor) function.**

How to use

The Light has 3 working modes. (AUTO – Motion Sensor, OFF & ON-stays on all the time)

1. Remove plastic protective film from the top of the light.
2. Pull out the plastic tab from battery compartment, on the remote control.
3. Slide the switch on the light to ON, the light will come on and stay on.
4. Slide switch to OFF, to turn the light off.
5. Slide switch to AUTO, to operate in the motion sensor mode. Light will work only in dark or shadowed/shaded areas. The light will turn on automatically when motion

is detected within range. The light will turn off automatically after approximately 90 seconds, or when no motion is detected.

6. Slide the switch to “OFF” to save battery power if you do not use the light for a long time.
7. Select Light Color (Warm or Cool), by pressing the round button on the top of light or on the remote control.
8. Control the light brightness by using the remote control. Push the 30% button to reduce the light brightness and to conserve battery life.
9. Push the + or – to increase or decrease the desired brightness.
10. Default brightness when turning on the light is at 100 % brightness.


How to use the timer function

Timer function only functions properly when the switch on the bottom of the light is in the ON position, do not use timer in AUTO mode.

1. Turn the switch on the bottom of the light to ON position.
2. Using the remote, push the button with the desired time to shut off (1 minute, 5 minutes, 15 minutes, or 30 minutes)
3. Light will blink twice letting you know the timer has been set to shut off in desired minutes selected.
4. If you push the wrong desired time button, simply push the correct desired time button, and it will override the previous selection.
5. To remove the timer function, turn the switch on the bottom of the light to OFF and then back to ON or AUTO.

How to charge the motion sensor led cabinet light

Please use 5V 1A power adapter and USB cord to charge the light, the indicator turns red when the light is charging, it turns green when the light is fully charged.



How to install the under-cabinet light

1. Stick it directly to any metal surface.



2. Use metal bracket with tape, to stick anywhere you want.



Specification

Product Dimension	11.8 x 1.6 x 0.90 inches
Input Voltage	120V 60Hz
Battery	3.7V 1000mAh
Charge Time	approx. 3-4 hrs.
Control Distance	approx. 9 – 16 Feet
Runtime	approx. 3-4 hrs. (100% brightness always on mode)
Lumen Output	160 lm \pm 10%
Standby Time	Approx. 90 seconds
Sensor Range	approx. 9- 16 Feet

Warning: Protect from heat, do not store over 122 degrees F.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.